

## **About Cautions**

CAUTION: A CAUTION indicates a potential for property damage, personal injury, or death.

## Removing and Installing a Fan Module



CAUTION: Only trained service technicians are authorized to remove the system cover and access any of the components inside the system. See your Product Information Guide for complete information about safety precautions, working inside the computer, and protecting against static discharge.

This document provides instructions about removing and installing a cooling fan module.



NOTE: See your Installation and Troubleshooting Guide for detailed instructions on removing or installing components.

## Removing a Fan Module

- **1** Remove the bezel (if applicable).
- 2 Turn off the system, including any attached peripherals, and disconnect your system from its electrical outlet.
- **3** Open the system.
- **4** Disconnect the fan module's power cable from the system board. See Figure 1.
- **5** Pull the fan straight up to clear the fan bracket.

## **Installing a Fan Module**



**NOTE:** The procedure for installing each individual fan is the same.

- 1 With the fan power cable facing down and towards the back of the system, route the fan power cable through the opening in the fan bracket and insert the fan module into the fan bracket. See Figure 1.
- **2** Reconnect the fan power cable to the fan power connector on the system board. See Figure 1.
- Close the system. See your Installation and Troubleshooting Guide.
- Reconnect your system and peripherals to their electrical outlets, and turn on the system.
- Replace the bezel (if applicable).






Figure 1. Removing and Installing a Fan Module

Information in this document is subject to change without notice. © 2004 Dell Inc. All rights reserved. Printed in the U.S.A.

Reproduction in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell and the DELL logo are trademarks of Dell Inc.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.