



# EasyCoder C4 Bar Code Label Printer

Intermec Printer AB Idrottsvägen 10 P.O. Box 123 S-431 22 Mölndal Sweden Service support: +46 31 869500

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Intermec manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Information and specifications in this manual are subject to change without notice.

© 2003 by Intermec Printer AB

All Rights Reserved

EasyCoder, EasyLAN, Fingerprint, and LabelShop are registered trademarks of Intermec Technologies Corp. The word Intermec, the Intermec logo, InterDriver, PrintSet, and Duratherm are trademarks of Intermec Technologies Corp.

The name Centronics is wholly owned by GENICOM Corporation. Kimdura is a registered trademark of Kimberly Clark. Microsoft is a registered trademark of Microsoft Corporation. Windows is a trademark of Microsoft Corporation.

Throughout this manual, trademarked names may be used. Rather than put a trademark (<sup>TM</sup>) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

## **Contents**

nternational Notices	v
FCC Notice	v
DOC Notice	v
EU Standard EN 55022	v
Wichtige Sicherhetshinweise	. vi
Safety Instructions	vii
Declaration of Conformity (CE)	viii
ntroduction	. ix

# **1** Installation

Unpacking	2
Power Connection	
Memory Cartridge	4
Installation of Memory Cartridge	
Computer Connection	
Centronics Parallel Interface	5
Serial RS-232 Interface	6
USB Interface	6
Software Installation	7

# 2 Operation

Controls and Indicators	10
On/Off Switch	10
Feed Key	
Indicator Lamp	
Media Compartment	
Media Load	
Introduction	13
Tear-Off	13
Peel-Off	13
Cut-Off	13
Label Taken Sensor	14
Tear-Off Operation	15
Peel-Off Operation	
Cut-Off Operation	
External Supply	
Ribbon Load	22

#### Preface

Loading a Fresh Ribbon Roll	.22
Removing a Partially Used Ribbon	
Label Gap Sensor	
Adjustment	
Test Mode	

# **3** Maintenance

External Cleaning	3
Printhead Cleaning28	3

# **4** Troubleshooting

Problems and Solutions or	Reasons
---------------------------	---------



# A Technical Data

# **B** Media Specifications

Direct Thermal Media	36
Thermal Transfer Media	37
Transfer Ribbons	38
Media Roll Size	39
Labels	40
Tags and Strip with Slots	41
Tags and Strip with Black Marks	
Plain Continuous Stock	43

# C Interfaces

Parallel Interface	
RS-232 Serial Interface	
USB Interface	

# 

### Firmware Upgrading

Requirements	50
Instructions	.51

### FCC Notice (United States of America)

#### WARNING

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and foun o comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

### DOC Notice (Canada)

#### **Canadian Dept. of Communication**

REGULATIONS COMPLIANCE (DOC-A)

This digital apparatus does not exceed the class A limits for radio noise emissions from a digital apparatus as set out in the radio interference regulations of the Canadian Department of Communication.

#### Ministère des Communications du Canada

CONFORMITE DE REGLEMENTS (DOC-A)

Le présent appareil numérique n'émet pas de bruits radio-électriques dépassant les limites applicables aux appareils numériques de classe A prescrites dans le règlement sur brouillage radioélectrique édicté par le Ministère des Communications du Canada.

#### EU Standard EN 55022 (The European Union)

#### WARNING

This is a Class A ITE product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

#### Preface

## Wichtige Sicherheitshinweise

- 1 Bitte lesen Sie diese Hinweis sorgfältig durch.
- 2 Heben Sie diese Anleitung für den späteren Gebrauch auf.
- 3 Das Gerät ist vor Feuchtigkeit zu schützen.
- 4 Beachten Sie beim Anschluß an das Stromnetz die Anschlußwerte.
- **5** Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
- **6** Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. elektrischen Schlag auslösen.
- **7** Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von autorisiertem Servicepersonal geöffnet werden.
- 8 Wenn folgende Situationen auftreten ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu Überprüfung.
  - a. Flüssigkeit ist in das Gerät eingedrungen.
  - b. Das Gerät war Feuchtigkeit ausgesetzt.
  - c. Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
  - d. Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
  - e. Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
- 9 Nur mit dem Schaltnetzteil Intermec/SPN-470-24 benutzen.

# **Safety Instructions**

- 1 Please read these safety instructions carefully.
- 2 Please keep this User's Guide for later reference.
- **3** Please protect this equipment from humidity.
- **4** Check the voltage of the power source before connecting the equipment to the power outlet.
- **5** If the equipment is not used for long time, disconnect the equipment from the AC voltage to avoid damage by transient over voltage.
- **6** Never pour any liquid into any openings, this could cause fire or electrical shock.
- 7 Never open the equipment. For safety reason, the equipment should only be opened by qualified service personnel.
- **8** If one of the following situations arises, get the equipment checked by a service personnel:
  - a. Liquid has penetrated into the equipment.
  - b. The equipment has been exposed to moisture.
  - c. The equipment does not work well or you can not get it work according to the User's Guide.
  - d. The equipment has dropped and been damaged.
  - e. If the equipment has obvious signs of breakage.
- 9 For use only with power supply Intermec/SPN-470-24.

#### **Declaration of Conformity (CE)** We. **Intermec Printer AB** Idrottsvägen 10 Box 123 S-431 22 Mölndal Sweden declare under our sole responsibility<sup>1</sup> that the product EasyCoder C4 to which this declaration relates is in conformity with the following standards Safety: EN 60 950:1992 + A1 + A2 + A3 + A4 + A11 EMC: **Based upon EN 50081-2 Generic Emissions Standard** EN 55 022:1994 EN 61 000-3-2/A12 Based upon EN 50 082-1 Generic Immunity Standard EN 61 000-4-2:1995 EN 61 000-4-3:1996 ENV 50 204:1995 EN 61 000-4-4:1995 EN 61 000-4-6:1996 following the provisions of Directives 89/336/EEC and 73/23/EEC Mölndal 2002-06-03 . . . . . . . . . . . . . . . PertOve Jacobsson Site Manager <sup>1</sup>/. Intermec assumes no responsibility regarding the CE Directive if the printer is handled, modified, or installed in other manners than those described inthe manuals.

# Introduction

Intermec EasyCoder C4 is a series of dedicated direct thermal and combined thermal transfer/direct thermal printers with a printhead density of 203.2 dots per inch (8 dots per mm) or 300 dots per inch (11.81 dot per mm).

The EasyCoder C4 printers are fitted with both a parallel Centronics port and serial RS-232 and USB ports.

As an option, the EasyCoder C4 can be fitted with a paper cutter that cuts continuous strip or liner between labels.

All EasyCoder C4 printers are delivered with the Intermec InterDriver for Microsoft Windows 95/98/Me, and Windows NT 4.0/W2000/XP. The InterDriver makes it possible to produce printouts from most standard programs run under the various versions of MS Windows.

Label design becomes an easy task with Intermec LabelShop, a series of "what-you-see-is-what-you-get" PC label-editing programs and compatible with the full range of Intermec EasyCoder printers. Intermec LabelShop START is included in the delivery.

EasyCoder C4 can also be run using ESim control commands described in the *EasyCoder ESim v4.00, Programmer's Reference Manual.* These control commands use short lines of ASCII characters to format the labels, enter text and bar codes and control the printing, making it possible to use a terminal or personal computer, that does not operate under MS Windows.

For comprehensive technical data, refer to Appendix 1.

#### Preface



This chapter how an EasyCoder C4 is unpacked, connected to a power source, and connected to a computer. It also explains how to install the software and how to expand the memory using a memory cartridge.

# Unpacking

Before starting the installation, carefully examine the delivery for possible damage or missing parts:

- **1** Open the box and lift up the power supply unit, cables, and other parts.
- **2** Remove the upper foam-plastic shock absorber and lift up the printer. Check that no visible damage has occurred during the transportation. Keep the packing material in case you need to move or reship the printer.
- **3** Check to make sure any options ordered are included.
- **4** Check the accessories included in the delivery. In addition to possible options, the box should contain:
  - Intermec EasyCoder C4 printer
  - Power Supply unit with either one power cord for 115V U.S. wall sockets or two different power cords for 230V European and 240V U.K. wall sockets
  - Parallel communication cable
  - Empty ribbon core (thermal transfer printers only)
  - Sample roll of labels
  - Media roll spindle
  - Quick-Start Guide
  - Manuals and an assortment of application software on CD-ROM.

Should any kind of damage have occurred during transportation, immediately make a complaint to the carrier.

Any incorrect delivery or missing parts should be reported to the distributor.



The discharge of electrostatic energy accumulated on the human body, the clothing, or other surfaces can damage or destroy the printhead or electronic components used in this printer. Avoid touching the electrical connectors while unpacking and setting up the printer.


## **Power Connection**

1 Place the printer in a suitable location that allows easy access to printed labels and preferably also easy reload of media and transfer ribbon. The printer should only be operated while resting on a horizontal surface, like a table or similar.



#### The printer and power supply unit must never be operated in a location where they can get wet. Personal injury could result! Only use with power supply Intermec SPN-470-24 P/N 1-092515-XX Mfg by PROTON.

- **2** Place the power supply in a suitable location between the printer and an electrical outlet, for example on the floor. The power supply can be used for 100 to 240 VAC, 50 to 60 Hz. The configuration of the power cord plug differs according to national standards.
- **3** Check that the printer's On/Off switch at the back is off (O).
- **4** First, fit the round connector into the power receptacle on the printer's rear plate. Then connect the power cord between the power supply and an AC wall socket.
- **5** The power can be switched on/off by means of the On/Off switch situated at the back of the printer. The indicator lamp on the printer lights green, red, or orange to indicate that the power is on. (It also indicates various conditions, see Chapter 2.)



On/Off switch

# **Memory Cartridge**


The EasyCoder C4 is fitted with a built-in flash memory where 214K is available to the user for storing forms, graphics, and fonts (see Appendix 1 for details). The built-in memory can be expanded using an exchangeable memory cartridge with 1MB flash memory and/or 256K SRAM.



When fitting or removing a memory cartridge, the power to the printer must be off!

### **Installation of Memory Cartridge**


- **1** Ensure that the On/Off switch on the printer is off (0).
- **2** Open the top cover by pressing the two locks on either side.
- **3** Remove the cartridge slot cover located to the left of the media roll. Be careful not to drop it inside the printer.
- **4** Ensure that the switch at the front short side of the cartridge is in its lower position.
- **5** Insert the memory cartridge into the cartridge slot. Its slightly curved shape ensures that the cartridge can only be fitted correctly. Push firmly to seat the cartridge.
- 6 Firmly close the top cover and switch on the power.



Intermec EasyCoder C4—User's Guide

# **Computer Connection**

All EasyCoder C4 models are fitted with a 36pin female Centronics connector for the parallel interface port, a DB-9pin female connector for the RS-232 serial interface port, and a USB connector. You can have cables connected to all these ports simultaneously, but only one can be used at a time.



#### **Centronics Parallel Interface**

If you intend to use the Intermec InterDriver or any version of Intermec LabelShop, connect the parallel communication cable delivered between the printer's Centronics interface connector and the parallel port of your PC (LPT1).

The parallel interface can also be used for programming the printer using the ESim protocol described in the *Intermec ESim v4.00, Programmer's Reference Manual.* However, prompts and other information from printer to host cannot be transmitted, since the parallel interface is one-way (host-to-printer) only.

### Serial RS-232 Interface

The serial RS-232 channel is intended for running the ESim protocol described in the *Intermec ESim v4.00, Programmer's Reference Manual*. It is not suited for the Intermec InterDriver driver.

The RS-232 communication setup is variable by means of the **Y** command (see *Intermec ESim v4.00, Programmer's Reference Manual*).

Use the Test Mode to check the printer's present setup (bold characters indicate default setup).

Baud rate:	1200, 2400, <b>9600</b> , or 19200
Parity:	None, Odd, or <b>None</b>
Data bits:	7 or <b>8</b>
Stop bits:	1 or 2
Flow control:	XON/XOFF and DSR/CTS



**Note:** No serial communication cable is included in the delivery unless specifically ordered. For pinout specifications, please refer to Appendix C.

#### **USB Interface**

The EasyCoder C4 supports USB v1.1 (also called USB 2.0 full speed). To use the USB interface for printing from a PC, you need a special Intermec USB printer driver installed in your PC.

The printer is a so called "self-powered device." We recommend that you only connect one printer to each USB port on the host, either directly or via a hub. Other devices, like a keyboard and a mouse, can be connected to the same hub. If you need to connect more than one Intermec USB printer to a host, you should use different USB ports.

Using a standard USB Class A/B cable, connect the Class A plug to your PC or hub and the Class B plug to your printer.

The USB interface is similar to the serial RS-232 channel, intended for running the ESim protocol.



**Note:** No USB communication cable is included in the delivery.

# Software Installation

If you intend to use the USB interface, you must start by installing the Intermec USB printer driver, which is included on the CD-ROM that comes with the printer.

If you run your EasyCoder C4 from a PC under Windows 95/98/Me, or Windows NT 4.0/W2000/XP, you may want to install the Intermec InterDriver and the Intermec LabelShop START found on the CD-ROM that comes with the printer.

If you use any other operating system than Windows, you will need to use the ESim protocol described in the *Intermec ESim v4.00*, *Programmer's Reference Manual*. (Intermec ESim also supports Windows.) Updates and installation instructions are available at the Intermec home page http://www.intermec.com.



**Note:** There are different firmware for the 203.2 dpi (8 dots/ mm) and the 300 dpi (11.81 dots/mm) versions.


#### Chapter 1— Installation



This chapter describes how to control the printer, how to load it with media and ribbon, how to adjust the label gap sensor, and how to use the test mode.

# **Controls and Indicators**

The EasyCoder C4 is controlled by the operator by means of an On/Off switch, a "Feed" key, and a multi-color indicator lamp.



### **On/Off Switch**

The On/Off switch is located at the back of the printer.

### **Feed Key**

The Feed key can be used in two ways:

- Tapping
- Holding

When power is first applied and the printer is loaded with media (and possibly ribbon), tapping the Feed key will initiate a formfeed, that is, media will be fed out to the top of next label or tag.

When power is first applied with no labels loaded, holding the Feed key will cause the media to be continuously fed out until the key is released. This mode is useful when replenishing the media supply.

After the media has been threaded through the printer, tapping the Feed key 3 more times (for a total of 4 taps) will cause a formfeed.

#### **Indicator Lamp**

When the power to the printer is switched on, the indicator lamp will glow green if the printer is loaded with media and—in case of thermal transfer printing—ribbon.

If the printer is out of media and/or ribbon, the indicator lamp will glow red.

Any error condition, such as label stop sensor problems, media jams, or software errors, will be indicated by the lamp changing to orange, except for media jams in the optional cutter, which are indicated by long red flashes.


If the indicator lamp fails to work as described above, please refer to Chapter 4 "Troubleshooting".

Color	Meaning
Green (solid)	Media loaded Ribbon loaded (TTR only)
- Green (flashing)	Receiving data (Test Mode only)
Red (solid)	Out of media Out of ribbon (TTR only) Printer reset
Red (short flashes	) Upgrading firmware Overtemperature
Red (long flashes)	Media jam in cutter Overheated printhead or stepper motor
Orange	Error condition detected or Bootloader active
Dark	Power off

# **Media Compartment**

The media compartment accommodates the media supply and, in case of thermal transfer capable printers, also the transfer ribbon supply (see illustration below).

In dedicated direct thermal printers, the top cover and the print mechanism are combined into a single unit.



# Media Load

#### Introduction

The EasyCoder C4 can print on heat-sensitive direct thermal paper, and in case of the thermal transfer model also on non heat-sensitive receiving face materials, in the form of self-adhesive labels, non-adhesive tags, or continuous stock. In case of non heat-sensitive face materials, a suitable thermal transfer ribbon must be used.

The media stock can be accommodated inside the printer in the form of a roll, or be placed behind the printer and inserted through a slot in the cover (for example fan-folded tickets or tags).

Three types of operation are available, Tear-Off (Straight-through), Peel-Off (Self-Strip), and Cut-Off:

#### Tear-Off

Tear-off (Straight-through) means that the media is fed straight out from the front of the printer and can be torn-off manually by pulling it upwards against the edge on the top cover. Tear-off mode can, for example, be used for tearing off tags at the perforation, or tearing off the liner (backing paper) between labels.

#### Peel-Off

Peel-off (Self-strip) means that self-adhesive labels are automatically separated from the liner (backing paper) after printing. It cannot be used in connection with a paper cutter. The labels are fed straight out from the printer, whereas the liner is fed out separately from a slot further down on the printer's front, from where it can be lead to for example a waste basket. Be careful when loading self-adhesive labels. If labels are not flat on the liner, the exposed edges can stick to your printer and cause problems.

#### Cut-Off

Cut-off requires an optional paper cutter fitted in place of a peel-off device and means that the liner of self-adhesive labels is automatically cut between labels or non-adhesive contionuous strip is cut into tickets and tags. The cutter is not designed to cut through any adhesive, which would stick to the cutting shears and prevent the cutter from operating.

#### Label Taken Sensor

The built-in Label Taken Sensor (LTS) can be enabled to hold the printing until the previous label (or similar) has been removed from the printer's outfeed slot. As long as the sensor detects a label, the printer will be BUSY and cannot receive data from host.

If using the ESim protocol described in the *ESim v4.00, Programmer's Reference Manual*, note the following:

- The LTS can be enabled/disabled manually using the switch next to the sensor (see below) or in the ESim protocol by an **O** command.
- When switching between peel-off, tear-off operation and cutoff operation, the media feed must be readjusted by means of a **j** command.

The Intermec InterDriver provides options for selecting the following modes of operation without any  $\mathbf{j}$  or  $\mathbf{O}$  commands having to be entered by the operator:


- Tear-off
- Peel-off with LTS enabled
- Peel-off with LTS disabled



#### If the printer runs out of media while printing, do not switch off the power during reload, or data will be lost!

The Label Taken Sensor can be enabled (on) or disabled (off) using a manual switch inside the peel-off mechansim.


## **Tear-Off Operation**



- 1 Open the printer's top cover by pressing the release buttons on both sides and folding the cover upwards/rearwards.
- **2** Pull up the spindle and remove possible remaining media or empty label roll core.
- **3** Place the spindle into the core of a fresh media roll. Rotate the spindle according to the inner diameter of the media roll core (see markings on the spindle).
- **4** Wind the green edge guide wheel towards the front of the printer so you can fit the media roll between the guides.
- **5** Place the media roll and spindle in the media compartment and snap the spindle into the slots on either side.
- **6** Wind the green edge guide wheel towards the rear of the printer so the rear edge guides just touch the roll without actually breaking its rotation.


#### Chapter 2— Operation

- 7 Route the media through the slits in the front edge guides
- 8 Firmly close the top cover.
- **9** If loading media for the first time or if changing from another type or size of media, perform a Label Gap Sensor Adjustment as described on page 24. Else, tap the Feed key either 4 times or until the indicator lamp glows green.
- **10** If the printer did run out of media while printing, the printing will automatically be resumed. Else, tear off excessive media by pulling it upwards against the tear bar.



Tear off the media upwards against the tear bar.


### **Peel-Off Operation**




- 1 Open the printer's top cover by pressing the release buttons on both sides and folding the cover upwards/rearwards.
- 2 Open the peel-off mechanism at the printer's front.
- **3** Pull up the spindle and remove possible remaining labels or empty label roll core.
- **4** Place the spindle into the core of a fresh label roll. Rotate the spindle according to the inner diameter of the label roll core (see markings on the spindle).
- **5** Wind the green edge guide wheel towards the front of the printer so you can fit the label roll between the guides.
- 6 Place the label roll and spindle in the media compartment and snap the spindle into the slots on either side.

#### Chapter 2— Operation

- **7** Wind the green edge guide wheel towards the rear of the printer so the rear edge guides just touch the label roll without actually breaking its rotation.
- 8 Thread the labels through the slits in the front edge guides.
- 9 Peel away the labels from the first 10 cm (4 inches) or so of the liner.
- **10** Thread the liner around the peel-off bar and insert it inside the peel-off mechanism so it protrudes from the slot below the mechanism.
- **11** Hold the labels while pulling at the liner so it becomes tight, then close the peel-off mechanism.
- **12** Firmly close the top cover.
- **13** If loading labels for the first time or if changing from another type or size of media, perform a Label Gap Sensor Adjustment as described on page 24. Else, tap the Feed key either 4 times or until the indicator lamp glows green.
- **14** If the printer did run out of labels while printing, the printing will automatically be resumed.



## **Cut-Off Operation**






- **Note:** The cutter cannot be used to cut through labels—only through the liner between labels—or the adhesive will stick to the cutting parts and prevent the cutter from operating properly. Media rolls must be wound with the printable side facing outward to prevent jamming the cutter.
- 1 Open the printer's top cover by pressing the release buttons on both sides and folding the cover upwards/rearwards.
- **2** Pull up the spindle and remove possible remaining media or empty media roll core.
- **3** Place the spindle into the core of a fresh media roll. Rotate the spindle according to the inner diameter of the media roll core (see markings on the spindle).
- **4** Wind the green edge guide wheel towards the front of the printer so you can fit the roll between the guides.

#### Chapter 2— Operation

- **5** Place the roll and spindle in the media compartment and snap the spindle into the slots on either side.
- **6** Wind the green edge guide wheel towards the rear of the printer so the rear edge guides just touch the media roll without actually breaking its rotation.
- 7 Thread the labels through the slits in the front edge guides.
- **8** Route the media through the slot in the optional cutter mechanism just in front of the tear bar.
- **9** Firmly close the top cover.
- **10** If loading media for the first time or if changing from another type or size of media, perform a Label Gap Sensor Adjustment as described on page 24. Else, tap the Feed key either 4 times or until the indicator lamp glows green.
- **11** If the printer did run out of media while printing, the printing will automatically be resumed.





# **External Supply**

Regardless of model and type of operation, direct thermal media or receiving face material (in the form of tags or labels) can be provided from an external supply, for example a stack of fan-folded tags.

Follow the loading instructions for the type of operation in question, but ignore all paragraphs concerning the internal spindle. Instead, insert the media through the slot at the back of the printer (see illustrations).

Be careful to protect any external media supply from dirt, grit, dust, water, and direct sunlight.





Thermal transfer ribbons are required when printing on non heatsensitive media. The type of transfer ribbon should match the face materials, so as to obtain the best durability and printout quality.

### Loading a Fresh Ribbon Roll

- 1 Open the printer's top cover by pressing the release buttons on both sides and folding the cover upwards/rearwards.
- **2** Press the green release tabs at the bottom of the top cover on both sides of the printhead and fold down the print carriage halfway (45° angle) while keeping the top cover fully opened.
- **3** Remove front core with the used-up ribbon and the empty core at the rear. Keep the empty core!
- **4** Unpack a fresh roll of transfer ribbon and route the ribbon leader down in front of the wall, that separates the print carriage from the media compartment, so the ribbon will feed from the top of the roll with the ink-covered side facing rearwards.
- **5** Install the ribbon roll in the rear position by placing one end over the left-side hub and pushing to the left. Then align the right end with the right-side hub and engage.

- 6 Similarly, install an empty core in the rewind (front) position.
- **7** Route the end of the transfer ribbon forward under the printhead and up in front of it. Using the tape fitted at the front of the ribbon leader, affix the leader to the top of the rewind core. Be careful to center-align the leader with the core.
- **8** Wind the green wheel on the right side of the rewind hub clockwise to wind up the leader onto the rewind core until the black ink-coated ribbon becomes visible. Remove any slack.
- **9** If so required, also load a fresh supply of receiving face material, for example labels, according to instructions earlier in this chapter.
- **10** Close the print carriage by pressing it firmly down simultaneously on both sides. A loud click indicates locked position.
- 11 Firmly close the printer's top cover.
- 12 Tap the Feed key until the indicator lamp becomes green.

#### **Removing a Partially Used Ribbon**

When switching between direct thermal and thermal transfer printing, or when switching between different types of transfer ribbon, a partially used transfer ribbon can be removed and saved for later use.

- 1 Open the printer's top cover by pressing the release buttons on both sides and folding the cover upwards/rearwards.
- 2 Press the green release tabs at the bottom of the top cover on both sides of the printhead and fold down the print carriage halfway (45° angle) while keeping the top cover fully opened.
- **3** Using a pair of scissors, cut the transfer ribbon just below the rewind roll.
- **4** Rewind the unused ribbon onto the supply spool. Remove the roll by pushing it to the left until the right end disengages and then lifting the roll up. Fasten the loose end with a piece of tape or label to prevent the roll from unwrapping.
- **5** Remove the rewind roll by pushing to the left and lifting up. Unwind the used ribbon into a waste basket or similar until you can dispose of it according to local environmental regulations. Keep the core! You will need it next time you load a ribbon.

# **Label Gap Sensor**

#### Adjustment

The EasyCoder C4 printer is fitted with a label gap sensor that detects slots between tickets and tags, or gaps between labels, as the media is fed past the sensor during printing. Thus the firmware can determine the length of the tags or labels and control the media/ribbon feed accordingly.

The label gap sensor is a center-aligned photoelectric sensor that measures the light that passes through the media path. The transparency of the liner of a label supply may differ between batches, making it difficult for the sensor to discriminate between labels and liner. When this occurs, the indicator lamp will switch from green to orange, indicating that sensor should be adjusted by entering the Test Mode, as described below.

# Test Mode

The Test Mode can be used for four main purposes:

- To adjust the Label Gap Sensor.
- To enter the Dump Mode.
- To print a Test Label with a test pattern and a list of the printer's current setup.
- To reset the printer to its default settings.



### Do not use continuous stock in the Test Mode. The printer will not be able to detect any gaps and an error will occur.

Use the Test Mode this way:

- 1 After having loaded the printer with full width labels, tickets, or tags, switch off the power to the printer.
- 2 Press and hold the Feed key while switching on the power.
- **3** Release the Feed key when the green indicator lamp flashes.

- **4** The printer will automatically adjust the label gap sensor and media feed according to the characteristics of the media. The printer may feed out 3-4 forms before the adjustment is completed. In case of peel-off operation, remove the labels as they are fed out.
- **5** After a delay, a Test Label will be printed and the printer will be placed in the Dump Mode (see *Intermec Esim v4.00, Programmer's Reference Manual*).
- 6a Tap the Feed key once to switch back to normal operation, or...
- **6b**...reset the printer to default setup values by pressing and holding the Feed key for at least three seconds after the test label was printed. The indicator lamp will switch to red to indicate that the printer was reset to default setup. Restart the printer by switching off the power and then switching it on again.

Refer to the *Intermec ESim v4.00, Programmer's Reference Manual* for illustration and explanation of the test label.

#### Chapter 2— Operation



This chapter explains how to clean the printer externally and how to clean the printhead.

The Intermec EasyCoder C4 printers are manufactured and tested under a strict quality management program. Only high quality components and materials are used in the printers. Although only minimal maintenance is required, following these simple maintenance procedures will ensure longer life with quality printing performance.

# **External Cleaning**

Keep your EasyCoder C4 clean by periodically wiping it with a soft cloth dampened with water. Do not use abrasive cleaners or solvents as they will scratch the surface.

# **Printhead Cleaning**

We recommend using the special Cleaning Card (part number 1-110501-00) and the procedures below to clean the printhead before loading each new roll of labels or tags.



# Cleaning Cards contain isopropyl alcohol $(CH_3)_2$ CHOH CAS 67-63-0 which is highly flammable, moderately toxic, and mildly irritating.

- **1** Switch off the power to the printer.
- **2** Open the top cover/print carriage.
- **3** Unload the media stock.
- 4 In case of thermal transfer printing, also remove the transfer ribbon.
- **5** Open the pouch and pull out the cleaning card. Be careful not to tear the card inside!
- **6** Insert the cleaning card under the print carriage the same way as when loading the media. Allow approximately 2 to 3 cm (1 inch) of the cleaning card to extend in front of the printhead.
- 7 Fold down the print carriage to locked position.
- **8** Use one hand to hold the printer and the other hand to pull the cleaning card forward, until the entire card has been pulled free.
- **9** Repeat steps 6, 7, and 8 a second time, then proceed at step 10.
- **10** Dispose properly of the used cleaning card and reload the media and ribbon supplies.



This chapter contains instructions for solving the most common problems the may occur when using an EasyCoder C4. The troubleshooting is restricted to the operator level. If the problem cannot be solved using this list, please contact the ditributor.

### Chapter 4—Troubleshooting

Problem	Solution or Reason			
Control lamp does not light green when power is on.	Make sure connectors on power supply are securely plugged into the receptacle on the printer and to an AC outlet.			
Control lamp lights	Label taken sensor active, label not removed.			
green but printer will not feed.	Make sure correct type of interface cable is securely plugged into both printer and computer.			
Printer seems to	Direct Thermal Printing:			
be working but nothing is printed.	Verify that the media is intended for direct thermal printing by testing if the paper is blackened by the heat from a hot object (+ 70°C/160°F or more).			
	Check that the heat-sensitive side faces the printhead.			
	Thermal Transfer Printing:			
	Verify that the printer is loaded with thermal transfer ribbon and that the ink-coated sided faces the receiving face material.			
Printing is faded.	Clean the printhead with the cleaning card.			
	If printing is still faded, increase the density setup.			
Prints only partial	Print carriage not completely locked.			
label.	Label caught on printhead. Remove and clean.			
Printer keeps printing or feeding	Label caught on label gap sensor. Open top cover. Remove the label and clean using cleaning card or isopropyl alcohol.			
when it should not.	Possible firmware problem.			
Printing stops and indicator lamp	Possible problem with label gap sensor. Perform an autoadjust in the Test Mode.			
lights orange.	Possible media jam.			
	Possible firmware problem.			
Label stuck on roller.	Open the peel-off mechanism and use fingers to peel away stuck label while manually rotating the roller. Do not use any sharp tools! Clean using a cleaning card or a cotton swab moistened with isopropyl alcohol.			
Label taken sensor does not hold	Label/tag bent down due to excessive length and/or too thin or soft media.			
printing until label/tag has been	Label/tag too short (less than 16 mm/.63 inches).			
removed.	Label taken sensor or cable defective.			
Indicator lamp flashes red, printing is interrupted	Overtemperature. Wait for the printer to cool down until the indicator lamp switches to green and the printing (if halted) is automatically resumed.			



This appendix lists the technical data for the EasyCoder C4.

### Appendix A— Technical Data

### General

Direct thermal and/or direct thermal/thermal transfer printing on self-adhesive labels, non-adhesive tags, or continuous stock. Internal media roll or external fan-fold supply. Tear-off /peel-off or cut-off operation

### Dimensions

Length:	259 mm	(10.20 inches)
Length with cutter:	290 mm	(11.4 inches)
Width:	230 mm	(9.06 inches)
Height:	166 mm	(6.54 inches)

### Net Weight

Thermal transfer printer, excl. power supply, media, cable, cutter, and memory cartridge:

2.30 kg (5.07 lbs)

4 VDC, 3.0A

100 to 240 VAC/50 to 60 Hz, 1.9 A

### Power

Separate power supply unit; Input: Output:

### Interfaces

1 × RS-232 serial (DB-9pin) 1 × Centronics parallel 1 × USB (v1.1)

### **Serial Communication**

Variable; XON/XOFF and DSR/CTS protocols.

### **Ambient Temperature**

Operation:	$+5^{\circ}$ C to $+40^{\circ}$ C	$(+40^{\circ}F \text{ to } +104^{\circ}F)$
Storage:	-20°C to +50°C	$(-4^{\circ}F \text{ to } +122^{\circ}F)$

### Humidity

10 to 90% RH, non-condensing.

### Ventilation

Free air.

### Printhead

Standard:

Option:

203.2 dots/inch (8 dots/mm) with 832 dots 300 dpi (11.81 dots/mm) with 1208 dots

### Printable Area

Width, max at 203.2 dpi Width, max at 300 dpi Length, max. (512K SRAM/203.2 dpi): Length, max. (512K SRAM/300 dpi):	104.0 mm 102.2 mm 472.5 mm 220.0 mm	(4.1 inches) (4.02 inches) (18.6 inches) (8.6 inches)
Media		
Roll Diameter, max:	125 mm	(5 inches)
Core Diameter, min/max:	25.4/38.1 mm	(1.0/1.5 inches)
Media Width, max:	116.0 mm	(4.57 inches)
Media Width, min.	25.4 mm	(1.0 inches)
Label Length, min:	6.35 mm	(.25 inches)
Max. Thickness, rolls:	0.15 mm	(.0006 inches)
Max. Thickness, fan-folds:	0.17 mm	(0.006 inches)
Min. Thickness, all:	0.06 mm	(.003 inches)

### **Thermal Transfer Ribbons**

Intermec transfer ribbons only (wax, hybrid, and resin) in widths of 33, 60, 63.5, 83.5, 89, and 110 mm (1.33, 2.36, 2.5, 3.29, 3.5, and 4.33 inches) centered on 110 mm (4.33 inches) wide cardboard cores.

Core inner diameter:	13 mm	(0.5 inches)
Max. ribbon roll diameter:	41 mm	(1.6 inches).
Ink coated side facing outwards, cores with notches		

### **Printing Speed**

8 dots/mm	30, 40, 50, or 75 mm/sec.
	(1.2, 1.6, 2, or 3 inches/sec.)
11.81 dots/mm	30, 40, or 50 mm/sec. (1.2, 1.6, or 2 inches/sec.)
	(1.2, 1.0, 01 2 menes/sec.)

### Sensors

Label gap, label mark, label taken, out-of-media, ribbon end, print frame open/closed.

### **Print Directions**

Text, bar codes, and graphics can be printed in four directions.

### Fonts

5 resident alphanumeric fonts (can be magnified up to 8 times horizontally and 9 times vertically)

### **Bar Codes**

Code 39 std. or extended Code 39 w. check digit

### Intermec EasyCoder C4—User's Guide

### Appendix A— Technical Data

Code 93 Code 128 UCC case code Code 128 A. B. C Codabar EAN 8 std, 2 digit add-on, or 5 digit add-on EAN 13 std, 2 digit add-on, or 5 digit add-on Interleaved 2 of 5 Interleaved 2 of 5 w. check digit Interleaved 2 of 5 w. human readable check digit Postnet 5, 6, 8 & 11 digit UCC/EAN 128 UPC A std, 2 digit add-on, or 5 digit add-on UPC E std, 2 digit add-on, or 5 digit add-on UPC Interleaved 2 of 5 PDF-417 MaxiCode Datamatrix

### Formatting

Print formats can be preprogrammed in flash memory

### Memory

Flash Memory:992K total. (778K firmware, 214K<br/>fonts, forms, and graphics)SRAM Memory:512K total203.2 dpi:120K firmware, 392K print buffer300 dpi:120K firmware, 392K print buffer


### **User Interface**

Keyboard:	One "Feed" button
Display:	1 multi-color LED indicator.

### Options

Memory Cartridge (1MB flash and/or 256K SRAM) Serial Communication Cable (RS-232) Parallel Communication Cable (Centronics) Paper Cutter Printhead V-spring for stiff/thick media Keyboard/Display Unit

34



This appendix specifies the physical characteristics and sizes for the direct thermal media, receiving face materials, and thermal transfer ribbons that can be used in an EasyCoder C4 printer.

# **Direct Thermal Media**

Intermec offers two quality grades of **direct thermal** media for the Easy-Coder range of printers:

# **Premium Quality**

Top-coated media with high demands on printout quality and resistance against moisture, plasticizers and vegetable oils. Examples...

Europe	North America
Thermal Top Board	Duratherm II,
Thermal Top	Duratherm II Tag
Thermal Top High Speed	Duratherm Ltg.
	Duratherm IR

# **Economy Quality:**

Non top-coated media with less resistance to moisture, plasticizers and vegetable oils. In all other respects, it is equal to Premium Quality. Examples...

### Europe

### **North America**

Thermal Eco

Thermal Eco Board

# **Thermal Transfer Media**

Intermec offers **stock** media for thermal transfer printing in a wide range of quality grades.

# **Uncoated Papers**

Used for economical high-volume printing in combinations with GP/ TMX 1100/TMX 1500 ribbons. Examples...

### Europe

### **North America**

TTR Uncoated

## **Coated Papers**

Coated papers havevarious coat-weight, smoothness, and gloss. To be used with HP/TMX 2500 and GP/TMX 100/TMX 1500 ribbons. Examples...

<b>Europe</b> TTR Matte	<b>North America</b> Duratran II
TTR Premium	Duratran II Tag
TTR Premium Board	Duratran II

# **Polyethylene Plastics**

Good resistance to water and many common chemicals. Can be use outdoors and offer good tear resistance. Most often used in combination with HP/TMX 2500 ribbons. Examples...

### Europe

TTR Polyethylene TTR Gloss Polyethylene **North America** Kimdura Kimdura Tag Syntran

# **Polyesters**

The materials of choice in combination with HR/TMX 3200 ribbons. Give high resistance to chemicals, heat, and mechanical abrasion. Examples...

### Europe

TTR High Gloss Polyester

### **North America**

Polyester

Intermec EasyCoder C4—User's Guide

# **Transfer Ribbons**

Intermec offer three types of thermal transfer ribbons optimized for different purposes:


- General Purpose (GP/TMX 1100, TMX 1500) transfer ribbons allow high speed printing and give a good printout, but are somewhat sensitive to smearing. They may be the best choice for uncoated and coated papers.
- High Performance (HP/TMX 2500) transfer ribbons allow high speed printing and gives a highly readable and defined printout on most face materials with smooth surfaces. They have good "smear resistance" and are most suitable for intricate logotypes and images on matte coated papers and synthetic face materials.
- High Resistance (HR/TMX 3200) transfer ribbons give an extremely durable printout, which is resistant to most chemical agents and high temperatures. However, such transfer ribbons set high demands on the receiving face material, which must be very smooth, such as polyesters.

The use of HR/TMX 3200 ribbons requires the print speed and the energy supplied by the printhead to be controlled with great accuracy according to the receiving face material. Consult your Intermec distributor.



**Note:** Intermec thermal transfer ribbons are engineered specifically for the EasyCoder printheads.

# **Media Roll Size**



### Core

Diameter:	25.4 or 38.1 mm	(1.0 or 1.5 inches)
Max. width:	118 mm	(4.65 inches)
Roll		
Max. diameter:	125 mm	(5 inches)
Max. media width:	116 mm	(4.57 inches)
Min. media width:	25 mm	(1 inches)
Max. media thickness:	0.15 mm	(0.006 inches)
Min. media thickness:	0.06 mm	(0.003 inches)

All types of media should normally be wound with the printable side facing outwards and unroll from the top of the roll. However tags and continuous strip can optionally be wound with the printable sidefacing inwards and unroll from the bottom of the roll as long as they are not used for cut-off operation.



Protect the media against sand, grit, and other hard particles during printing and storage. Keep the cover closed. Even very small foreign particles may cause severe harm to the delicate printhead.

# Labels

### $\leftarrow$ a $\rightarrow\,$ Media width (incl. liner):

Maximum:	116.0 mm	(4.57 inches)
Minimum:	25.0 mm	(1 inches)

### $\leftarrow$ b $\rightarrow$ Label length:


Minimum:	6.35 mm	(.25 inches)
----------	---------	--------------

### $\leftarrow$ c $\rightarrow$ Label gap height:

Maximum:	10 mm	(.39 inches)
Minimum:	2 mm	(.08 inches)

### Liner:


Opacity: 75%



# **Tags and Strip with Slots**

$\leftarrow$ a $\rightarrow$ Tag or strip width:					
Maximum:	116.0 mm	(4.57 inches)			
Minimum:	25.0 mm	(1.00 inches) (0.25 inches)			
$\leftarrow$ b $ ightarrow$ Tag length:					
Minimum:	6.35 mm	(0.25 inches)			
$\leftarrow$ c $\rightarrow$ Detection slot width:					
Minimum:	14 mm	(0.55 inches)			
$\leftarrow \mathbf{d} \rightarrow ~\mathbf{D}\mathbf{e}\mathbf{t}\mathbf{e}\mathbf{t}\mathbf{i}\mathbf{o}\mathbf{n}$ slot height:					
Maximum:	10 mm	(0.39 inches)			
Minimum:	1 mm	(0.08 inches)			

The label gap sensor is offset 4.5 mm (0.177 inches) to the right of the center of the media path.




# Tags and Strip with Black Marks

### $\leftarrow$ a $\rightarrow$ Tag or strip width:

Maximum:	116.0 mm	(4.57 inches)		
Minimum:	25.0 mm	(1.00 inches)		
$\leftarrow$ b $ ightarrow$ Tag length:				
Minimum:	6.35 mm	(0.25 inches)		
$\leftarrow$ c $\rightarrow$ Detection slot width:				
$\leftarrow$ c $\rightarrow$ Black mark width:				
Minimum:	28 mm	(1.10 inches)		
$\leftarrow d \rightarrow $ Black mark height:				
Maximum:	10 mm	(0.39 inches)		
Minimum:	3 mm	0.012 inches)		

The black mark sensor is offset 10 mm (0.394 inches) to the right of the center of the media path.

Max. reflectance 5% at 940 nanometer. Carbon black.



# **Plain Continuous Stock**

The EasyCoder C4 can use continuous stock without any detection slots or black marks. The printer must be set for continuous stock by the **Q** command (see *Intermec ESim v4.00, Programmer's Reference Manual*).


The length of each copy is decided by the size of the print image and any additional media feed is decided by the Q command.

Continuous stock cannot be used in the Test (Dump) Mode.

# Maximum: 116.0 mm (4.57 inches) Minimum: 25.0 mm (1.00 inches)

### $\leftarrow$ a $\rightarrow$ Tag or strip width:

Appendix B— Media Specifications



This appendix describes the signals on the serial RS-232 port and the parallel IEEE 1284 port. The USB port has a standard USB socket.

# **Parallel Interface**

Handshake:

DSTB to printer and BUSY to host.

Printer connector:

36-pin female Centronics connector.

Pin	Signal Name	Transmitter	
1	-Strobe	Host	
2–9	Data 0–7	Host	
10-11	Busy	Printer	
12	Paper empty	Printer	
13	Select	Printer	
14–15	Not connected		
16	Signal ground		
	17	Chassis ground	
18	+ 5V DC	Max. 500 mA <sup>1</sup>	
19–30	Signal ground		
31	-Init		
32	-Fault	Printer	
33	Signal ground		
34–36	Selectin		

 $^{1}$ /.The combined load on the external +5V on both the parallel and the serial port must not exceed a total of 500 mA.

# **RS-232 Serial Interface**


Printer connector:

DB-9pin female RS-232 connector.


	Host		EasyCoder C4	Host		
Signal	DB-9	DB-9	Signal	DB-9	DB-25	Signal
		1	+5V 500 mA1	1		
RXD	2	2	TXD	2	3	RXD
TXD	3	3	RXD	3	2	TXD
DTR	4	4	_	4	20	DTR
GND	5	5	GND	5	7	GND
DSR	6	6	RDY	6	6	DSR
RTS	7	7	-	7	4	RTS
CTS	8	8	RDY	8	5	CTS
		9	-	9		

 $^{1}/. The combined load on the external +5V on both the parallel and the serial port must not exceed a total of 500 mA.$ 

# **USB Interface**



Printer end of USB cable



Computer end of USB cable



This appendix describes how to upgrade the printer's firmware.

# Requirements

There are two methods to upgrade the printer's firmware:

# Using a PC

To upgrade the printer's firmware via a cable connection from a PC running MS Windows, you will need the following:

- The Intermec EasyCoder C4 Config Tool. This is a free software running under Microsoft Windows<sup>1</sup>. It makes it possible to download various firmware version either directly to the printer or to a memory cartridge. It also supports font downloading and memory partitioning. The Config Tool supports seven languages and comes with a comprehensive on-line help in English.
- An upgrading file (.ufz). The Intermec EasyCoder C4 Config Tool comes with a collection of firmware upgrading files. New files can be downloaded from the Intermec Web site (http://www.intermec.com) and should be located in the subfolder "Firmware."
- A host computer running Microsoft Windows with a parallel, USB, or RS-232 connection to the EasyCoder C4. (Parallel or USB connections are recommended.)
- Optionally a memory cartridge with 1 MB flash and 256K SRAM (P/N 1-092103-00).

# Using a Memory Cartridge

To upgrade the printer's firmware using a memory cartridge, you will need the following:

• A factory-programmed upgrading memory cartridge from Intermec (recommended if you cannot use MS Windows) or a upgrading memory cartridge created using the Intermec EasyCoder C4 Config Tool.

<sup>1</sup>/. Supported versions of MS Windows: Windows 95, Windows 98, Windows Me, Windows 2000, and Windows XP.


# Instructions

# Using a PC

- 1 Install the Intermec EasyCoder C4 Config Tool in your PC.
- **2** Run the C4Conf.exe program.
- **3** Set up the parameters for the firmware download. Use the on-line help for instructions.
- **4** Start the Firmware download wizard and follow the instructions on the screen.

# Using a Memory Cartridge

- **1** Switch off the printer.
- **2** Move the switch on the side of the cartridge to the upper position.



- **3** Insert the cartridge.
- **4** Switch on the printer. The indicator lamp will start blinking during the upgrading. Wait until the blinking stops, which takes about 40 seconds.
- **5** Switch off the printer and remove the memory cartridge. Put back the cover over the memory cartridge slot.



# If the cartridge is removed at an angle, the connector pins may be bent.

- 6 Press the Feed key and keep it pressed and at the same time switch on the power to the printer (also see "Test Mode" on page 24). A test label will be printed. Check the version number on the test label to verify that the upgrading has been successful.
- **7** Tap the Feed key once to leave the Dump Mode and return to normal operation.
- 8 You can use the same memory cartridge to upgrade several printers by moving the cartridge from printer to printer and repeat this procedure for each printer. Be careful not to change the position of the memory cartridge switch until all printers have been upgraded.
- **9** The cartridge can be used as a normal memory expansion cartridge after the upgrading is completed. Move the switch back to normal position, insert the cartridge in a printer, and switch on the printer. The memory cartridge will then be formatted automatically.



Intermec Printer AB Idrottsvägen 10, P.O. Box 123 S-431 22 Mölndal, Sweden tel +46 31 869500 fax +46 31 869595 www.intermec.com

EasyCoder C4—User's Guide



\*1-960572-01\*